

SKIRTING TO UPSTAND - Cover Flashing

Carefully rake/cut the joint to a depth of not less than 25mm, at a height of 150mm minimum above the finished waterproofing surface. The chase should be below the level of any DPC of cavity tray.

Apply sufficient coats of the specified BÖRNER PRIME COATING to the detail.

Apply the specified BÖRNER Vapour Control Layer to the primed upstand & dressed to link with the Underlayer by 50mm minimum.

Apply the specified PIR Insulation to the Vapour Control Layer, to be bonded as per BÖRNER Specification Proposal.

Provide 50mm x 50mm specified BÖRNER Angle Fillets to the junction of all horizontal & vertical abutments

Apply the specified waterproofing detailing fully bonded to the upstand. Detailing Underlayer and Cap Sheet must be lapped and fully sealed onto the main area as indicated.

Provide suitable lead-free flashing to the provided chase lengths not exceeding 1.5m ensuring end laps are not less than 100mm & that a minimum cover of 75mm is provided to the upstand.

The chase should then be pointed with a one or two part polysulphide sealant or suitable mastic sealant.

NOTES:

Completed waterproofing upstand details should always be installed so as to achieve a height of 150mm minimum above the finished roof level.


All details to be installed in accordance with BS8217, BS6229, and BÖRNER recommendations.

All waterproofing detailing must be undertaken as two layers and as separate items.

All surfaces must be clean, dry, and suitably prepared to accept the waterproofing system.

During the application of all bitumen membranes a visible bead of bitumen must be exuded from all side and end laps.

Any upstands in excess of 250mm should be mechanically fixed at the leading edge with appropriate fasteners in order to avoid slippage of the waterproofing membrane.



Copyright Reserved - Please note that this drawing & the copyright therein is the property of BÖRNER & is issued on the understanding that the drawing or any detail thereof will not be divulged to a third party unless written permission is first obtained from BÖRNER technical services department. The drawing is valid only when approved by the Architect / Contractor concerned.

This detail is representative of a typical situation and provided for illustration purposes. Insulation thickness shown may differ in accordance with specifiers U value requirement.

Standard Detail

Drawing Title:

Skirting to Upstand - Cover Flashing

Date:
2018

Notes / Revisions:

Scale:
NTS

Drawing No.

B1

Drawn By:
BÖRNER



BÖRNER. Systematically sealed.

Email: info@borner.ie